Quick Reference Manual 5536 CASIO

Congratulations upon your selection of this CASIO watch.

 $\mathsf{Bluetooth}^{\texttt{@}}$ is a registered trademark or trademark of Bluetooth SIG, Inc. of the United States.

Your watch has a Mobile Link function that allows it to communicate with a Bluetooth® mobile phone and adjust its time settings to match those of the mobile phone

- This product complies with or has received approval under radio laws in various countries and geographic areas. Use of this product in an area where it does not conform to or where it has not been approved under applicable radio laws may be punishable under local laws. For details, visit http://world.casio.com/ce/BLE/.
- Use of this product inside of an aircraft is restricted by the aviation laws of each country. Be sure to obey instructions provided by flight personnel concerning use of devices such as this product.


Visit the website below for the operation manual (Operation Guide) of this watch.

http://world.casio.com/manual/wat/



Using the Watch

General Guide




- 1 n m indicator (No indication for a m.)
- 2. Summer time indicator
- 3. Alarm enabled indicator
- 4. Hourly time signal enabled indicator
- 5. Hands shifted indicator
- 6. Auto Light enabled indicator
- 7. Stopwatch Mode
- 8. World Time Mode
- 9. Mobile phone connection
- 10. Battery status
- 12. Mobile phone connection standby
- 13. Alarm Mode
- In the Timekeeping Mode, hold down (B) for about 1.5 seconds to establish a Bluetooth connection with a phone.

Selecting a Mode

Each press of © cycles between modes as shown below.

• Hold down © for at least two seconds to enter the Timekeeping Mode.

Timekeeping



Setting the Time

- In the Timekeeping Mode hold down
 (A). Release the button when [SET] stops flashing and the Home City name
- Each press of © or © changes the
- Home City setting.

 2. Press © to move the flashing to the summer time (DST) setting.

 The control of the control of
 - Press (D) to cycle between the available summer time (DST) settings (AUTO, OFF, ON).
- 3. Press © to display the seconds setting screen.
- . This causes the seconds count to



- 4. Press (D) to reset the seconds count
- 30 to 59 seconds: Adds 1 to minutes.

- 5. Press © to move the flashing to the hour setting.
- 6. Use (i) and (ii) to change the hour setting.
- 7. Press © to move the flashing to the minute setting.

 8. Use ① and ② to change the minute
- settina
- Press © to move the flashing to the year setting.
- 10. Use (1) and (2) to change the year setting.
- 11. Press © to move the flashing to the month setting.

 12. Use © and © to change the month
- 13. Press © to move the flashing to the day setting.
- 14. Use (a) and (b) to change the day setting.
- 15. After all the settings are the way you want, press (A) to exit.

Specifications

Alarms:

Other:

Power Supply:

Accuracy at Normal Temperature: ±15 seconds per month average when time adjustment by communication with a phone is not possible.

Analog Timekeeping: Hour, minute (moves every 10 seconds), second

Hour, minute, second, month, day, day of the week, a.m./p.m. (P)/24-hour timekeeping, Full Auto Calendar (2000 to 2099), Digital Timekeeping:

Summer Time

39 cities (39 time zones) and Coordinated Universal Time (UTC) Other: Standard Time/Daylight Saving Time (summer time);
Home Time City/World Time City swapping; direct UTC World Time:

recall

Measurement unit: 1/1000 seconds (first hour); Stopwatch:

1/10 seconds (after first hour)
Measurement range: 23 hours, 59 minutes, 59.9 seconds
Measurement functions: Normal elapsed time; split time

Unit: 1/10 seconds Range: 24 hours Time setting unit: 1 second Time setting range: 1 second to 24 hours

10-second beeper when the end of the countdown is reached

5 (Configurable as Daily, One-time, Scheduled)
Setting units: Hour, minute (Daily or One-time)
Year, month, day, hour, minute (Scheduled)
Alarm tone duration: 10 seconds
Hourly time signal: Beep every hour on the hour

Auto time correction Mobile Link:

Auto time correction
Time setting adjusted automatically at preset time.
One-touch time correction
Manual connection and time adjustment
Phone finder
Watch operation sounds the alert sound of the mobile

World Time

Current time for approximately 300 cities selected for the

Current time for approximately 300 cities selected for the watch
Home Time/World Time swapping
Auto summer time switching
Automatic switching between standard time and summer time
Time action

Timer setting

Timer setting
Alarm setting
Hand position correction
Data Communication Specifications
Bluetooth®
Frequency band: 2400 MHz to 2480 MHz
Maximum transmission: 0 dBm (1 mW)
Communication range: 2 meters max.
(depends on envir

(depends on environment)

High-brightness DOUBLE LED light; illumination duration setting; Auto Light; Power Saving; Battery power indicator; operation tone on/off; Hand Shift; Alarm Countdown

Solar panel and one rechargeable battery Approximate battery operating time: 6 months under the

following conditions:

• Auto time correction: 4 times/day

Alarm: Once (10 seconds)/day
 Illumination: Once (1.5 seconds)/day

Specifications are subject to change without notice